

PONTOON AND TRITOON KIT INSTALLATION MANUAL

MODELS



Paradise Dock & Lift Inc.



READ CAREFULLY & RETAIN THIS DOCUMENTATION PRIOR TO INSTALLATION AND USE!

4311A 25 Ave. Vernon, BC V1T 1P5 Local: 250-503-8630 Toll Free: 1-888-411-3625

info@paradisedocklift.com www.paradisedocklift.com Issued: 2022-12-01 COPYRIGHT © 2021 PARADISE DOCK & LIFT

CONTENTS

Intro + Hardware	2
Safety Information	3
Liability Disclaimer	4
Terminology Specific to This Manual	5
Assembly Instructions	6
Warranty	10

INTRO + HARDWARE

Congratulations on acquiring your new Paradise pontoon or tritoon bunk system!

This manual is intended to be used in conjunction with the installation manuals for 2 or 4 cylinder lifts. Refer to this manual for H-frame spacing and bunk placement of pontoon and tritoon kits only.

Pontoon/Tritoon Hardware				
Qu	antity	ltem		
Pontoon	Tritoon			
8	8	3/8" x 7" Hex Bolts		
12	16	3/8" x 4" Hex Bolts		
4	4	1" x 7 1/8" Pontoon Bunk Pins		
4	4	1" Bunk Pin Washers		
4	4	1/8" x 2" Cotter Pins		
20	24	3/8" S.S. Flat Washers		
20	24	3/8" Kep Nuts		
-	2	1/2" x 3/4" Hex Bolts		
-	6	1/2" Flat Washers		
-	2	1/2" Aluminum Nuts		

SAFETY INFORMATION

Always read and obey all safety messages and instructions when assembling, installing or operating the boat lifting system or its accessories. Boat lifts are heavy equipment that pose major hazards. Your safety is of utmost importance so if there is any misunderstanding with information contained in this manual, please contact your dealer or the manufacturer. Important safety messaging will be outlined as follows:



Note:

Paradise Dock & Lift Inc reserves the right to make changes to this product and manual at any time without notice. This manual includes the latest information at the time it was printed and the product was shipped. This manual should be kept available to whoever is using this product.



- Never allow any persons to go under or on the lift particularly when it is operating or supporting a load.
- All persons must stay clear of lift while the lift is in operation.
- Never service a boatlift, boat or boatlift accessory while the lift is supporting a load.
- Your lift system is not intended to support people, never actuate the lift with people on-board. Unload and load passengers only when the boat is floating and not supported by the lift.
- Never exceed the lift's rated capacity. The gross/ loaded weight of your watercraft should always be less than the lift capacity as indicated on the serial plate.





Only operate the system to lift the watercraft, do not use the system for other purposes or items.

- The lift should only be operated by adults or under direct adult supervision. Anyone who operates the lift must be fully aware of the information outlined in this manual.
- Do not play on or around the lift.
- It is not possible for the manufacturer to identify all hazards surrounding the site assembly, installation and operation of a lift system.
 Owners, dealers, and installers must use good judgement to assess risk, and make installation, maintenance, and operation decisions: Do not operate in poor conditions, when system is not level, or when noticeable corrosion/damage/ defects are present.
- Failure to properly position boat on lift could make the lift unstable.
- Keep long hair, loose clothing, and jewelry away from any moving parts.



- During the first few operations of the lift, the weight of the watercraft may cause the lift to settle. Stay well away from the lift during actuation until it is seen that the installation is stable.
- The frame structure, welds, bolt and pin conditions should be inspected for issues such as corrosion and wear annually.
- Do not store items in the power pack box, items may damage hydraulic and electrical systems.




- Leave the lift in the fully "up over centre" position during storage, this is the safest position.
- Do not position the lift near areas where people swim or dive frequently. When it is lowered, swimmers may inadvertently hit the lift causing injury.
- Ensure that the lift remains level within 2 inches. Out-of-level lift installations may be unstable and increases the risk of capsizing and injury.
- Never disconnect hydraulic hoses with a watercraft on the lift.
- Never enter the lift while the boat is under power. Glide in at a slow speed. The lift is not designed to take large impacts from a fast moving boat. Large impacts may cause damage to the lift.
- It is recommended that the lift be partially raised out of the water if people are swimming in the vicinity. Use the remote to raise the lift when departing so swimmers can see the location of the boat lift.

LIABILITY DISCLAIMER


Installation and assembly instructions provided are intended for authorized Paradise Dock & Lift dealers and installers. If you require assistance, please contact Paradise Dock & Lift to be put in contact with a dealer in your area who can safely assemble and install this system. An installer must determine if they have the necessary experience, knowledge and skills to safely assemble and install a this system. If there is any confusion, please contact Paradise Dock & Lift. Improper assembly and/or installation may cause a risk to property, safety or lift functionality/reliability. A failure to correctly follow assembly and installation instructions constitutes a waiver of the installers rights against Paradise Dock & Lift for subsequent damages. The installation instructions provided are not a warranty or guarantee, best judgment must be used during installation.




TERMINOLOGY SPECIFIC TO THIS MANUAL



ID #	Name
1	H-frame Center Beam
2	Cross Bar
3	Middle Bunk Support
4	Cross Bar Mounting Bracket
5	H-frame Side
6	H-frame





lssued: 2022-12-01 Rev. 1

ASSEMBLY INSTRUCTIONS

Tools Required:

- 9/16" wrench, socket and ratchet
- 3/4" wrench, socket and ratchet
- 5/16" Allen key
- Needle nose pliers
- Anti seize

- Marine grease
- Rubber mallet
- Tape measure
- Pencil/pen



WARNING! - Follow all assembly instructions, failure to assemble lift as described may lead to warranty issues, hazards, or the lift misfunctioning. WARNING! - Apply anti-seize to ALL stainless steel bolts.


WARNING! - Do not install washers under kep nuts. Kep nuts with washers are more likely to back off.

Step 1: Position the Main Beams

The center to center distance between the outer pontoons of the watercraft will be the center to center distance of the main beams.

Make sure the main beams are evenly spaced from the center of the end beams.

Use the 3/8"-16 x 4.5" hex bolts, 3/8" washers, and 3/8"-16 kep nuts to hold the beams in position. Do not fully tighten until H-frames are fully installed.



Step 2: Assemble and Install the H-frames


Check your boat lift manual for front/back H-frame identification.


Slide the H-frame center beam into the H-frame sides and lift the H-frame assembly onto the frame. Secure with pins, washers, and cotter pins.

Alternatively, you may be able to install each side of the H-frame separately, then slide the center beam through one side to the other. Some grinding on the inside of the H-frame tube.

Center the center beam between the two H-frame sides. Double check your center to center distance. Drill four 17/32" holes in each center beam using the holes in the H-frame sides as a guide, then bolt it together.

Install Cylinders








Install the cylinders according to your boat lift

Install the outer bunks with the 7" bunk pins, 1" washer, and cotter pin.



Issued: 2022-12-01 Rev. 1


Step 3:

manual.

Step 5: Install Cross Bar Mounting Brackets

Install the mounting brackets in front of the range extenders. Installing in the wrong place will result in parts being pinched between the H-frame and the bunks.

Use 3/8"-16 x 7" hex bolts, 3/8 flat washers, and 3/8"-16 kep nuts.




Step 6: Install Cross Bars

Slide the cross bars through the mounting brackets.


Center the cross bars and middle bunk mount (if applicable) between the bunks and drill 7/16" holes where required for the mounting brackets and middle bunk support.

Secure cross bars with 3/8"-16 x 4 1/2" hex bolts, 3/8" flat washers, and 3/8"-16 kep nuts.




Step 7: Install Center Bunk (Tritoon Only)

Install the middle bunk onto the middle bunk supports with 3/8"-16 x 7" hex bolts, 3/8" flat washers, and 3/8"-16 kep nuts.



Step 8:Install Guide Ons (Optional)

Slide guide ons onto the cross bar and secure with 3/8"-16 x 4 1/2" hex bolts, 3/8" flat washers, and 3/8"-16 kep bolts.



WARRANTY

PARADISE DOCK & LIFT INC.

15 YEAR LIMITED WARRANTY

Paradise Dock & Lift Inc. ("Paradise") warrants to the original purchaser that its parts for residential use are free from defects in materials and workmanship as stated in this Limited Warranty during the Warranty Period as identified herein. The Warranty Period begins on the date of purchase as shown on its receipt or invoice. The Limited Warranty is not transferrable or assignable. Any product used commercially or for non-residential use is limited to a 1-year warranty.

Dock Frames: Roll-In Dock, Sectional Dock, Floating Docks – 15 Year Warranty Period

Paradise will provide replacement parts, on a non-pro-rated basis, for five (5) years from the date of purchase for these items if they are found to be defective in workmanship. After this 5-year parts warranty, an additional tenyear pro-rated warranty covers these components as shown below. Aluminum decking is warrantied for 5 years, the warranty does not include paint fading, paint wear, scratches, and denting. Third-Party components carrier their respective warranty from their manufacturer.

The pro-rated schedule of these items is as follows:

Year After Purchase	Consumer Portion of	Year After Purchase	Consumer Portion of		
	Current Retail Price		Current Retail Price		
6	5% Parts Only	11	50% Parts Only		
7	10% Parts Only	12	60% Parts Only		
8	20% Parts Only	13	70% Parts Only		
9	30% Parts Only	14	80% Parts Only		
10	40% Parts Only	15	90% Parts Only		

Boat Lift Frames - 15 Year Warranty Period

Paradise will provide replacement parts, on a non-pro-rated basis, for five (5) years from the date of purchase for these items if they are found to be defective in workmanship. After this 5-year parts warranty, an additional tenyear pro-rated warranty covers these components as shown below. This is exclusive of the hydraulics, hoses and powerpack, which parts only have three (3) years coverage from the date of purchase if found to be defective in workmanship.

The pro-rated schedule of these items is as follows:

-		2	
Year After Purchase	Consumer Portion of	Year After Purchase	Consumer Portion of
	Current Retail Price		Current Retail Price
6	5% Parts Only	11	50% Parts Only
7	10% Parts Only	12	60% Parts Only
8	20% Parts Only	13	70% Parts Only
9	30% Parts Only	14	80% Parts Only
10	40% Parts Only	15	90% Parts Only

Dock Accessories, Boat Lift Accessories, Wheel Kits & Tires – 3 Year Warranty Period

Defects in the material and workmanship of certain accessories of Paradise dock and boat lift systems are covered under a three (3) year pro-rated warranty. Items covered include wheel kits, plastic wheels/tires, benches (except cedar boards), bumpers, dock stairs, ladders, dock furniture/tables, kayak/canoe rack/ flagpole, shore-end ramps (except cedar boards), support poles, poly decking, hammocks, guide-ons, bow-stops, canopies, walkways and powerpack brackets.

This Limited Warranty is for the repair or replacement of parts only. If you discover a parts defect, you must notify your local Paradise dealer or distributor, in writing, of any claim under this Limited Warranty. Your written notification must include proof of purchase which includes the original name, address, and details about the warranty claim. At Paradise's request for confirmation of defect, you are responsible for returning the part to your local Paradise's dealer or distributor. The replacement part shall be warranted for the balance of the Warranty Period remaining on the original part.

AFTER RECEIVING NOTIFICATION OF THE DEFECT, PARADISE WILL, AT ITS DISCRETION, REPAIR, REPLACE, OR, IF PARADISE DETERMINES IN ITS SOLE DISCRETION THAT REPAIR OR REPLACEMENT IS NOT FEASIBLE, REFUND THE PURCHASE PRICE OF THE PART FOUND ON EXAMINATION BY PARADISE TO BE DEFECTIVE UNDER NORMAL USE AND SERVICE. IN ORDER TO ALLOW PARADISE AN OPPORTUNITY TO ASSESS THE CONDITION OF THE PART FOR WHICH A WARRANTY CLAIM IS MADE, YOU SHALL PROVIDE REASONABLE ACCESS TO THE PART TO PARADISE AND/OR ITS AGENTS, WHICH INCLUDES PARADISE DEALERS OR DISTRIBUTORS. TO FACILITATE THE PROMPT ASSESSMENT OF YOUR WARRANTY CLAIM, PARADISE MAY, FROM TIME TO TIME, REQUIRE THAT YOU PROVIDE ADDITIONAL DOCUMENTATION, PHOTOGRAPHS AND OTHER INFORMATION. FAILURE TO PROVIDE THE FOREGOING WITHIN A REASONABLE TIME FROM THE DATE OF REQUEST BY PARADISE WILL INVALIDATE YOUR LIMITED WARRANTY.

Routine maintenance and checking for loose connections or damaged parts must be performed on a monthly basis. Paradise shall not warrant and cover any damage caused by circumstances outside the reasonable control of Paradise, or defect in the parts directly or indirectly, or wholly or partly attributable to:

(a) the misuse, negligence, abuse, neglect, improper installation, including any damage to the parts resulting from alterations or modifications made by any person not authorized by Paradise;

(b) exposure of the parts to snow or ice, salt water use, natural expansion or contraction of parts caused by weather conditions, severe weather conditions, storms, vandalism, being hit by another a watercraft, terrorism, or acts of God;

or


(c) accident, overloading, power surges, corrosion, or operation of the parts on circuits or voltage other than those specified to the parts.

THIS LIMITED WARRANTY IS YOUR EXCLUSIVE WARRANTY AND REPLACES ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Some provinces or jurisdictions do not allow limitations on how long an implied warranty lasts, so the above duration may not apply to you.

IN NO EVENT SHALL PARADISE, ITS SUBSIDIARIES, PARENT, SUPPLIERS, DEALERS, DISTRIBUTORS, RESELLERS OR SERVICE PROVIDERS BE LIABLE FOR: (i) third party claims against you for damages; or (ii) special, incidental, indirect or consequential damages, including lost profits, business revenue, goodwill or anticipated savings, these exclusions apply even if paradise has been advised of the possibility of these damages and even if any remedy fails of its essential purpose. Subject to this paragraph, any claim for damages for breach of warranty shall be limited to the purchase price of the part.

NOTHING IN THIS LIMITED WARRANTY AFFECTS STATUTORY RIGHTS THAT CANNOT BE WAIVED OR LIMITED BY THIS LIMITED WARRANTY.



Paradise Dock & Lift Inc.

4311A 25 Ave. Vernon, BC, Canada V1T 1P5 paradisedocklift.com info@paradisedocklift.com 1-888-411-3625

SPECIFICATIONS & INSTRUCTIONS SUBJECT TO CHANGE WITHOUT NOTICE. COPYRIGHT © 2021 PARADISE DOCK & LIFT INC.